

## **Flashing a WD MyNet Router**

Use this method if you cannot flash your router using the “upgrade” image.

Give your computer a static IP Address of 192.168.1.10

This will ensure that the computer can talk to the router when flashing the new firmware. A tutorial on doing this is available at <http://ofmodemsandmen.com/static.html>

Unplug the power to the router and use an Ethernet cable to connect from the router Lan port to your computer.

Using a paperclip, press and hold the reset button on the bottom of the router and turn it on.

Hold the reset button for at least 15 seconds. At this point, the blue power LED will be blinking.

Use your browser to go to 192.168.1.1 and upload the ROOter file with “factory” in its name.

When the router has finished rebooting go to 192.168.1.1 with your browser and you will see the ROOter login screen.

Restore your computer so it gets an automatic IP address. The tutorial on doing this is available at <http://ofmodemsandmen.com/static.html>