

Wifi7 routerboard DR9574 command to set card slot

4x4 single radio

setenv machid 8050e01

setenv bootargs 'console=ttyMSM0,115200n8

cnss2.enable_qcn9224_support=1 cnss2.bdf_pci2=0x0002

cnss2.bdf_pci3=0x0004 cnss2.enable_mlo_support=0'

saveenv

2x2 dual radio

setenv machid 8050e01

setenv bootargs 'console=ttyMSM0,115200n8

cnss2.enable_qcn9224_support=1 cnss2.bdf_pci2=0x1006

cnss2.bdf_pci3=0x1003 cnss2.enable_mlo_support=0'

saveenv

imgaddr=0x50000000 && source \$imgaddr:script && reset

0002 represent DR9274-5G radio

0004 represent DR9274-6G radio

1006 represent DR9274-5G6G radio

1003 represent DR9274-2.4G5G radio